

Figure 1 - Side view of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage.



Figure 2 - Complete side view of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage.



Figure 3 - Front view of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage.



Figure 4 - Close-up front view of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage.



Figure 5 - Complete front view of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage. Shows routing of wire rope through stirrup and into hoist.



Figure 6 - Close-up view showing routing of wire rope through stirrup and into hoist. Path of wire rope is through top of stirrup, under top pulley, over bottom pulley, through sky lock, and into hoist.



Figure 7 - Close-up back view of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage.




Figure 8 - Close-up of hoist's stirrup strap mounted on Walk-Thru stirrup of MKD Work Cage.



Figure 9 - Operator using the hoist controls of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage.



Figure 10 - Operator using the optional pendant controls of Compact hoist mounted on Walk-Thru stirrup of MKD Work Cage.



Figure 11 - View of an optional 6-Foot Pendant Control (P/N: 41021752-6) and its connection on the Compact hoist. Pendant Control is connected by simply removing the Jumper Plug connection from back of hoist and connecting the Pendant Control connection*. Hoist can then be operated by either the hoist mounted controls or the pendant controls.

*NOTE: For added safety, it is always best to remove the voltage power source from the unit, before removing or connecting any connections.