

# Bosun Chair Instructions

Part Number: 104-43



For use with Sky Climber™ Compact Electric and Air Hoists, LNX hoists, and most competitor's hoists.

## INSTALLATION

- 1) All stirrup attachments bolt to the strap on the bottom of the Bosun Chair frame. Use bolts provided with the hoist.
  - a. Sky Climber Compact Hoists will align with the middle hole.
- 2) The Sky Lock™ should be attached to the upper portion of the tube.
- 3) Beginning in 2020, every Sky Climber Bosun Chair will come equipped with a short rubber hose that attaches to the bottom of the tube. Use this hose to protect the wire rope when using any Compact Series hoist on the bosun chair.
- 4) Feed wire rope through the Sky Lock™, into the tube, and into the hoist.
- 5) The Footrest Assembly is removable when necessary for access into restricted areas.
- 6) A 6-foot pendant is recommended for use with this bosun chair for ease of operation. Pendants sold separately.



## OPERATION

- 1) Follow hoist instructions provided with the hoist attached to the bosun chair at time of operation. Follow all manufacturer's safety instructions pertaining to operation and maintenance.

Description	Part Number
Bosun Chair complete assembly	104-43
Part No. Chair Replacement	104-42
Part No. Front Wheel Only	104-29
Part No. Rear Wheel Only	104-36